


STEP 4. Tap to list item to start homing



Shows distance, relative elevation (if available), stationary time (if user not moving) and connection status.

STEP 1. Unplug from charger OR press button to turn on the Proximity Beacon



Top LED

- Solid Green: Starting Up/Powering Down
- Blinking Green: On, not connected to Proximity App
- Blinking Blue: Connected to Proximity App
- Blinking Red: Low battery

Charging LED

- Solid Green: Charging
- Green: Charged
- Off: USB Disconnected
- Blinking Green/Orange: Charging Error


After pairing, place in pocket for protection from direct heat.

STEP 3. Ranging Begins Automatically when Paired

Lists all Proximity Units in range and their distance. Turns red after 30 s if user is not moving. To set device "friendly name", app will read NFC text tag.



STEP 2. Bluetooth Pair with Android



In the App – choose Proximity Device (S/N is found on the top back label)

**NFC must be enabled (Settings/NFC) and phone must be on and unlocked for Touch Pairing to work.*

Touch NFC enabled Android proximity device to initiate Bluetooth pairing – Accept pairing when prompted.

